


Pre-punched Tap Hole Guide

Applicable for Sergio Ceramic Mansion-02P

Important

This must be removed prior to installation of the sink by a professional. Failure to do so will void the warranty. Due to individuality of these sinks we strongly recommend that a registered joiner / plumber be used to complete the install.

Tools Required



Sharp Ended Nail Punch



Hammer



Pencil or Marker




Notes

It is highly recommended that safety goggles and gloves are worn when knocking through the tap hole.

Procedure

1. Identify the centre of the pre-punched hole that you wish to use. Mark the centre on the small enamelled side (glazed surface) of the sink.
DO NOT try to knock out the hole from the underneath (Fig. 1).
2. Place the sink in a well supported position.
3. Take a sharp ended nail punch and placing a soft cloth underneath, place the point onto the mark made. Using a hammer, strike firmly the top of the punch until the point has been broken through to the underside of the pre-punched hole (**Fig.2**).
4. Carefully chip away the remaining material to gradually enlarge the tap hole until you have removed the entire pre-punched hole (**Fig.3**).
5. You should then find the tap mixer you intended to use, will fit the hole.

Due to our policy of continual improvement, we reserve the right to change specifications without prior notice.



0800 222 764